Ŋ Z >

INSTRUCTIONS **ASSEMBLY**

Read these instructions carefully before proceeding

to the locking pin. Tighten the end bracket over the support locking bolt on the end of the leg, making sure it slides down appropriate step, slide the Position main leg on the

MAIN

Set locking pins to height of the step the main leg will rest on.

Position support

leg at base of

BRACKET

SUPPORT EG

11 LOCKING BOLT

OCKING SAFE WORKING LOAD 250 kg **SPECIAL NOTES:** Ų,

CROSS

the upright of the main leg and rest firmly on the stair tread Tighten locking bolt through the bracket on Slide the bracing leg

as left or right hand side of the stainwell depending on access to NOTE: Either leg set can be used locking bolts. set -repeat steps 1 to 4. To erect the second leg

> tighten thumb screws desired working height and relocate the locking pins and push up the top cross rail to the your foot on the bottom cross rail, Remove locking pins from

support you working platform

The Stairman is now ready to

and bolts are in position and

CROSS

the top of main legs. Keeping

NOTE: If access is restricted, the bolts retaining the cross rails. apart as the cross rails and stairs will allow and tighten the locking cross rails, position leg sets as wide When you have erected the second leg set, slide in the

the Stairman moved into position cross rails can be fitted and then

Derby DE21 4SZ Tel: 0332 299069 Mansfield Road 29 The Parker Centre

FOR WORKING ON STAIRS WITH OPEN

BALUSTRADING